

Refer to the bullet length chart (see reverse) to confirm the two detent balls are installed in correct holes of bullet feed sleeve. Detent balls are installed in upper holes from factory.

2. Thread die into the press a couple of turns.

3. Place a flared case into shell plate.

4. Fill the bullet feed sleeve with bullets, base down, with one protruding.

5. Raise case to top of stroke. Screw die clockwise until the bullet stack drops plus an additional $\ensuremath{\!\!\!\!^{1\!\!2}}$ turn.

6. Finger tighten lock ring, tighten split clamp with 3/32" hex key.

TIPS FOR SUCCESS:

I Change ball position over a tray or container to prevent losing balls. (Replacements #92002) 2 Keep bullet stack near the top of the sleeve, weight of bullets aids in seating a bullet into the case. 3 Adequate case mouth flare is required to reduce bullet tipping.





LEE INLINE BULLET FEED DIE



WARNING: This product may contain steel alloyed with trace amounts of lead and other elements which are known to the State of California to cause reproductive harm and cancer. For more information, go to www.P65Warnings.ca.gov. To prevent

exposure, do not alter the product by welding, grinding, etc.

