

User Manual

Thermal Imaging Monocular

CYCLOPS SERIES








Table of Contents

About This Manual	4
Regulatory Information	5
1. Introduction	6
1.1 Device Description & Features	6
1.2 Detection Range	8
1.3 Application Scenarios	8
1.4 Cautions	8
2. Packing List	9
3. Operation Guide	9
3.1 Battery Charging	9
3.2 Power on/off	10
3.3 Buttons and Controls	10
3.3.1 Buttons Features and Introduction	10
3.3.2. Lens Adjustment	11
3.3.3 Rocker Button Operation	11
3.3.3.1 Zoom	11
3.3.3.2 Pseudo Color Switch	12

3.3.3.3 AI Ranging	13
3.3.4 Capture/Record	13
3.4 Settings	13
3.4.1 Image Setting	13
3.4.2 System Setting	14
3.4.3 Network Connection	15
3.4.3.1 App Download	15
3.4.3.2 Connect via Wi-Fi	16
3.4.3.3 Connect via Hotspot	16
3.4.4 APP Push Notification	17
3.4.5 File Management	18
3.5 External Video & Data Reading	19
3.6 System Software Upgrade	19
4. Technical Data	20
4.1 Product Size & Drawing	20
4.2 Specifications	21

About This Manual

COPYRIGHT © 2022 ThermTec Technology Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of ThermTec Technology Co., Ltd. or its subsidiaries (hereinafter referred to be "ThermTec"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of ThermTec. Unless otherwise stipulated, ThermTec does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

This Manual is applicable to Thermal Imaging Monocular.

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons.

Regulatory Information

Œ

This product and, if applicable, the supplied accessories are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Radio Equipment Directive 2014/53/EU, the EMC Directive 2014/30/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.



1.1 Device Description & Features

Device Description

ThermTec Cyclops Series Thermal Imaging Monocular, the new generation intelligent thermal imaging monocular, is designed with a 12µm uncooled infrared detector and can be equipped with 15mm/25mm/35mm lens and 1024x768 OLED high-definition display. With AI image recognition algorithm, it enables users to get clear views under various lighting conditions, even in complete darkness, providing reliable and high-quality visual images for night activities. In particular, the function of easy connection to mobile phones enables users to share views in real time.

Features

1. Mechanical Rocker Design

It balances the central of gravity, providing an easier and outstanding handheld experience.

2. 12µm VOx Detector

The 12µm VOx detector provides images with better quality, and ensures perfect detail recognition.

3. OLED Display

Designed with 1024x768 OLED display, it brings outstanding HD image quality as well as great durability, making it operable in a broader temperature range as low as minus 20°C.

4. Al Intelligent Ranging

Based on the deep learning algorithm, the monocular can automatically measure the object distance.

5. Two-way Wi-Fi Design

It supports both WIFI and hotspot connection, which allows users to share images and videos with friends in real time.

6. Photo and Video Playback

Integrated pictures and video recording makes sharing the thermal action quick and easy, with the functions of playback and APP sharing.

7. Long Battery Life

Built-in battery with up to 12H super long standby, recording every and instant moment of your hunting and outdoor experience.

8. GPS Function

Enable user to know his own coordinates in real time, which makes field activities safer.

9. Smooth Zooming

Continuous 1.0-6.0 HD zooming ensures excellent sharpness and the highest resolution of details from minimum to maximum magnification.

10. IP67 Protection Design

Provided with IP67-rated weatherproof performance, it is capable of capturing images/videos through rain, snow, smoke, smog, or dust.

1.2 Detection Range

The illustration below shows the comparative range performance of the camera with different lens configurations. The data is based on detecting a man 1.8 meters tall*0.5 meters wide.



1.3 Application Scenarios

- Animal Observation
- Outdoor Adventure
- Security Law Enforcement
- Emergency Search and Rescue

1.4 Cautions

- 1. Prevent hard objects from colliding the lens and eyepiece of the thermal imager to avoid damage to the optical lens.
- 2. Do not aim the lens at high-temperature light sources, such as the sun, to avoid damage to the lens or thermal imaging detector.
- 3. Do not use the product in extremely cold or hot environment. Refer to the product parameter table for specific temperature requirements.
- 4. If the thermal imager is not used for a long time, it should be charged once every 3 months during the storage period.
- 5. To use the product in water environment, first make sure that the USB cover at the bottom of the thermal imager is tightly closed.
- 6. Do not irradiate the laser indicator of the thermal imager to human eyes.
- 7. If the thermal imager doesn't work properly, please contact the store or the nearest service center where the thermal imager is purchased. Do not disassemble or modify the thermal imager by yourself in any way.

Packing List

Monocular	1
Lanyard	1
USB cable	1
Video output cable	1
Carry bag	1
User manual	1





USB cable (x1)



Carry bag (x1)



Lanyard (x1)



Video output cable (x1)



User manual (x1)

3 Operation Guide

3.1 Battery Charging


The battery should be fully charged prior to use.

Note: The battery is not user replaceable.

Follow the below steps to charge the battery:

1. Lift the cover from the USB port.

Plug the cable provided into the USB port.
Plug the opposite end of the cable into a USB power source.



Notes: When the charging indicator on the device becomes red, it means you need to charge the device immediately. The indicator turns to red when it is charging and turns to green when it finishes charging. After it turns to green, stop charging.

3.2 Power on/off

alla	Power on	Power off
U	Hold the POWER button for four seconds and the boost screen will be shown.	When the device is turned on, hold the POWER button for four seconds to power off the device.

Note: Refer to Figure 1 for the main view of the monocular.

3.3 Buttons and Controls

3.3.1 Button Features and Introduction





Figure 1

	Press and Hold	Press	Double- Click
ථ	Power on/off	Laser indicator on/off	Standby mode on/off
Ø	Take videos	Take photos	
	⊕ Zoom in ⊖ Zoom out	Peseudo color switch	Main menu


Diopter Adjustment

Looking through the eyepiece, adjust the position of diopter level to optimize the image sharpness on the OLED display.




Objective Lens Focusing

Manually adjust the objective lens focus when necessary.



3.3.3 Rocker Button Operation

3.3.3.1 Zoom



3.3.3.2 Pseudo Color Switch

Use rocker button towards right to switch pseudo color.



There are six color palettes by default. You can choose the pseudo color you want by customizing. Unwanted colors can be turned off in the system setting.

			1.0	x <u></u> @ 9	?≈∎021:04
	Ranging				
	Coordinate				
	Reticle				
	OLED	m/yd			
	Correction	Color	Redhot	OFF	
	System		Green	ON	
-	Tracking	Update	Golden		
•	GPS	Lang	Violet		
۲	OSD	Timezone			
	LED	Blindpixel			

Color Palettes



White



Black



Red



Green



A Company

Golden

Violet

3.3.3.3 Al Ranging

Use the rocker button towards left to enable or disable AI ranging function (before this function is enabled, please make sure the device is in AI ranging mode. Otherwise, refer to Section 3.4 for setting).



Al Ranging Function

3.3.4 Capture/Record

Press O to take photos. Then the photo icon in the upper left corner will flash once.

Press and hold to take videos. Then the recording icon in the upper left corner starts flashing, and the recording starts timing. Press and hold again to stop recording.

3.4 Settings

Double-click the rocker button to enter Setting menu.

Note: Select by moving the rocker button, and short-press the rocker button to confirm the selection.

3.4.1 Image Setting

Press to enter the Imaging Setting menu. There are five sub-menus for image setting, which are "Image Mode", "Sharpness", "Denoise", "Brightness" and "Contrast".

		(1.0X 🖬 🗆 ♥ 📚 🖬 14:33)
	Mode	
	Sharpness	
•	Denoise	
\oplus	Brightness	
	Contrast	

Image Setting		
Mode	Object mode	Especially enhance target's detail. It's recommended to be used in bad weather conditions.
	WDR mode	Gain both background and target's detail with wide dynamic algorithm.
Sharpness	0-10	Adjust image sharpness to make the image edge sharper. The recommended value is 5.
Denoise	0-10	Adjust image noise to make the image cleaner. The recommended value is 5.
Brightness	1-10	Adjust image brightness to make the image brighter. The recommended value is 5.
Contrast	1-10	Adjust image contrast to make the target more prominent in the image. The recommended value is 5.

3.4.2 System Setting

Press it o enter the System Setting menu. Select by moving the rocker button, and short-press the rocker button to confirm the selection.

	Ranging
	PIP
1.00	Coordinate
	Reticle
	OLED
	Correction
	System
-	Tracking
•	GPS
\oplus	OSD
	LED

System Setting			
EIS		Electronic Image Stabilization. Can be turned on/off in the system setting.	
Ranging	Al	AI distance measurement	
	MIL	MIL distance measurement	
PIP	Picture- in- picture	In the picture, the image is 2x enlarged from the center of the cross.	

Coordinate		The position of the crosshair in
		the picture can be adjusted
		and separately saved.
Reticle	0-7	Choose the style of the
		crosshair. "0" represents none,
		and "1-7" represents seven
		different styles.
OLED	Hue	Blue, purple and gray are
OLLD	1100	optional for OLED hue.
	Brightness	
Correction	Manual/	The mask works to calibrate
CONECTION		
0	Auto	the uniformity of images.
System	Reset	All configuration parameters
		are restored to the factory
		default values after resetting.
	Update	You can adjust and upgrade
		the device system.
	Languag	Support multiple languages.
	е	
	Time zone	Select local time zone and
		adjust the date and time.
	Blind pixel	The blind pixel in the picture
		can be replaced.
Heat		Turn on heat tracking to mark
Tracking		the target with the highest
naoking		temperature in real time in the
		screen.
GPS		Turn on GPS function to obtain
0.3		real-time satellite positioning,
		longitude and latitude
		coordinates and time
		information.
OSD		Turn off OSD.
LED		Turn off LED. The work
		indicator is turned off and the
		hidden work mode is started.

EIS function: Turn on the EIS function to reduce the impact of body shaking on the image and keep the image stable when observing distant targets.

Note: EIS function is only available for CP635/CP650.



3.4.3 Network Connection

Press to enter the Network Connection menu.

3.4.3.1 APP Download

Search "Smart Thermal" in APP store, or scan the below QR code to download the APP.



3.4.3.2 Connect via Wi-Fi

① Open smart device's personal hotspot.

⁽²⁾ Short-press the rocker button to enter the sub-menus of Network Connection, and select WIFI for configuration.

③ Access the Wi-Fi sub-menu on monocular and select the Wi-Fi released by smart devices, and then enter the password through the rocker button to connect the Wi-Fi.

④ After the monocular is connected via Wi-Fi, open the mobile APP to connect the monocular.



3.4.3.2 ①

3.4.3.2 ②




3.4.3.3 Connect via Hotspot

(1) Short-press the rocker button to enter the submenus of Network Connection, and select WIFI for configuration.

2 Access the Hotspot sub-menu, and the monocular will release a hotspot network. Set the hotspot name and password and confirm them through the rocker button.

③ Enable mobile device to connect with monocular Hotspot by setting the WLAN on mobile device.

④ After mobile device is connected with monocular Hotspot, open the mobile APP to connect the monocular.





3.4.4 APP Push Notification

The APP push notification function can detect and identify the target type (human or animal) in real time, measure the distance, and pop up a push notification on the APP.


The specific operation steps are as follows:

Note: Android phones can get push notification always on display by launching the APP in the background. (1) Turn on AI and ranging function on the device.



(2) Connect the APP with the device (follow Section 3.4.3). Select "Alarm" and " Open" to turn on the push notification.







3.4.5 File Management

Short-press to enter the File Management menu. Select the image and video sub-menus to view the images and videos and play the videos.

	1.0X 🗔 🗆 오 📚 💶 15:26
₽	
Image	
📄 Video	

File Setting	
Image	Access the Image sub- menu, and select photo files through the rocker button for management.
Video	Access the Video sub- menu, and select video files through the rocker button for management.

3.5 External Video & Data Reading


Power on the device before using a type-C to AV video cable to output analog video. When external display is connected, the OLED of the device automatically turns off the display.

Power on the device, use a type-C to USB cable to connect with the computer to read the video and image data in the memory.

Note: video and image taken in analog format (usually taken by external display with analog output) will be saved in folder named "720", video and image directly taken by monocular will be saved in folder named "1024".

3.6 System Software Upgrade

① Connect the device to your computer and drag the upgrade file to the folder.





2 Access the Setup menu and select Upgrade.

③ The system will prompt that upgrading is in progress. When the upgrade succeeds, the device will restart automatically.




Technical Data









4.2 Specifications

Туре	CP315	CP325	CP335	CP635	CP650	
Sensor Parame	ters					
Detector Type	Vox Microbolometer					
Resolution/ Pixel pitch	384 x 288/12µm			640 x 512/12µm		
NETD	≤40mk@300k			≤35mk@300k		
Frame Rate	8-14µm	8-14µm			8-14µm	
Spectral range	50Hz			50Hz		
Lens	15mm	25mm	35mm	35mm	50mm	
FOV	17.5° x 13.1°	10.5° x 7.9°	7.5° x 5.6°	12.5° x 10°	8.8° x 7.0°	
Identification Distance (1.8m man)	375m	627m	878m	878m	1250m	
Imaging Proces	ssing					
Digital zoom	1~6 continuous					
Color Palette	5+					
Noise Reduction	3D noise reduction					
Image Enhancement	IDE; HDR					
Display						
OLED	0.39 inch; 1024x768 resolution					
Diopter Control	-5~+5					
Eye Distance	40mm					

Function				
OLED	3 modes			
Language	English			
Reticle	6+; adjustable coordinates			
Memory Card	16G			
Al Distance Measurement	Yes			
Photo, Record, Playback	Yes			
Heat Track	Yes			
Lasor Indicator	Yes			
GPS	Yes			
Power				
Battery Type	Internal Cell (18650 x 2)			
Battery Life	Continuous working time ≥12h			
Interface				
Type-C	Power charge; data reading; output analog video			
Wi-Fi	Two-way Wi-Fi connection; APP remote control			
Environmental Parameters				
Working Temperature	-20°C~+55°C			
Protection Level	IP67, 1 meter drop resistance			
Physical Parameters				
Weight	470g (with battery)			
Size	67mm x 63mm x 190mm			
Accessories				
External Cable	Analog video cable; USB data cable			
Other Accessory	Wrist strap; plush bag; user manual			